

# TECHNICAL ADVICE DOCUMENT Wide coil in well using Hampshire frame

### 1. This Technical Advice Document applies to:

600 mm minimum sheet width 2000 mm maximum diameter Sheet width > diameter/2.5

- Wide coils, loaded bore horizontal in a well trailer.
- Coils are classed as **stable** or **topple sensitive** based on the ratio of outside diameter (OD) to sheet width (SW).
- Hot rolled coils (not pickled and oiled) up to 30 tonnes.
- Low friction coils up to 25 tonnes.




- The following coils are classed as *low friction*:
  - Coils that have been wrapped in plastic film or paper.
  - Coils that have been pickled and oiled, galvanised, painted or coated.
  - Cold rolled coils.

#### 2. Equipment requirements

- All webbing straps must have a minimum lashing capacity of 2000 daN (unless otherwise stated) and must be compliant with EN 12195-2.
- All lashing points must have a minimum working load limit of 2000 daN (unless otherwise stated).
- Edge protection must be used on all unprotected sharp corners.
- Well posts must be in good condition and have a minimum moment capacity of 14.6 kNm. The following section sizes in S355 steel are acceptable: 80 x 80 x 5; 90 x 90 x 4; 100 x 60 x 5; 100 x 100 x 3.6; 110 x 60 x 4; 120 x 60 x 3.2. Note: Rectangular posts must be used in the strongest orientation to prevent bending.

## 3. Pre-loading considerations

- ✓ Well width must be a minimum of 1100 mm.
- ✓ Well angle must be a minimum of 30 degrees.
- ✓ Coil well must be dry and clear of debris and other loose items.
- ✓ Coil must be clear of well base by a minimum of 20 mm.




## TECHNICAL ADVICE DOCUMENT

# Wide coil in well using Hampshire frame

#### 4. Restraint system options

#### 4.1 General restraint system



- Maximum gap of 20 mm between 
  √ Stable coils coil face and blocking.
- 1 strap over-the-top.
- Frame straps to be anchored a minimum of 500 mm from rear face of coil.

Anti-slip matting shown for coils originating in mainland Europe.


- Timber dunnage stacked between the coil and well posts minimum recommended timber size 100 x 100 mm (nom).
- Steel well posts may be used as blocking with anti-slip matting between the horizontal faces of the steel posts.
- The *minimum* blocking height to prevent the coil from toppling is shown in Table 1. The maximum blocking height is 450 mm to prevent the posts from bending.
- Well boards may also be used in the upright position as a form of blocking between the vertical well posts and coil providing they do not exceed 450 mm - see TIS-0006.
- Dunnage must extend beyond outer edges of the trailer well and well posts.

✓ Topple sensitive

#### Table 1: Minimum blocking height (mm)

Coil Outside Diameter	Minimum blocking height
1400	100
1500	150
1600	190
1700	230
1800	270
1900	300
2000	340
Max heigh	t 450

#### 4.2 Option for stable coils, and for topple sensitive coils up to 10 tonnes



For topple-sensitive coils above 10 tonnes use Section 4.1. Weight limits for stable coils are as stated in Section 1.






- Place coil directly against well posts. Maximum gap of 20
- Coil diameter must extend beyond the outer edges of the well post.
- 1 strap over-the-top.
- Frame straps must be anchored a minimum of 500 mm from rear face of coil.

Anti-slip matting shown for coils originating in mainland Europe.

#### 5. Rearward blocking



Frame straps must be anchored a minimum of 500 mm from rear face of coil (see 4.1 and 4.2).

Number of frame straps can be reduced by 1 when using strap with lashing capacity (LC) of 5000daN attached to lashing points with minimum working load limit of 3500daN.

Anti-slip matting shown for coils originating in mainland Europe.

Care has been taken to ensure that the contents of this publication are accurate, but Tata Steel Europe Limited and its subsidiaries do not accept responsibility or liability for errors or information that is found to be misleading.